



Read All Section Before You Install

To get latest information,
please visit our website: www.homywpc.com

These installation guidelines will direct you through the process of installing HOMY products. These installation methods are recommended by HOMY, but they may not cover every installation scenario you may encounter. Since each installation is unique in its performance requirements, the ultimate installation method used is the sole responsibility of the installer. HOMY recommends that all designs be reviewed by a licensed architect, engineer or local building official before installation. Make sure your plans meet local building codes before you begin the installation.

Safety

Appropriate safety equipment is necessary when you deal with any type of construction project. HOMY highly recommends, but is not limited to the following safety equipment: gloves, a respiratory protection, long sleeves, pants, and safety glasses.

Planning Ahead

To determine how much HOMY board/sheet material you will need, start by calculating the square footage of your wall surface by multiplying length by width. When calculating the amount of board/sheet you will need, it is recommended that you add roughly 10% to the total for a scrap factor. A layout for your board/sheet should be planned before starting installation to ensure the best possible looking panel for your project. Building codes and zoning ordinances generally apply to permanent structures, meaning anything that's anchored to the ground or attached to the house. So nearly every kind of board/sheet requires permits and inspections from a local building department. We recommend drawing out a site plan of your proposed project that you intend to do to minimize errors and make your perfect wall board/sheet.

Expansion and Contraction

HOMY board/sheet planks will experience expansion and contraction with changes in temperature. Expansion and contraction are most significant where extreme temperature changes occur. Changes in length are most significant during the installation process, and should be taken into account if working in extreme temperatures. A good example would be cutting your planks during a hot afternoon, letting them sit outside overnight in the cool air and then installing them the next morning, and you will notice a certain amount of contraction. The best way to minimize this problem is to fasten your planks after cutting as soon as possible.

01 HOMY WPC

Read All Section Before You Install

To get latest information,
please visit our website: www.homywpc.com

Environment

You need a clean, smooth, flat and strong surface to install HOMY products. Make sure your plans meet local building codes before installing any type of board/sheet if installation is not that urgent.

Tools & Accessories

The tools you need for this installation are illustrated below:



Electric Drill

Guiding Rule

Tape Measure

Saw

Accessories



Double-sided Tape

Structural Adhesive


Nail-free Adhesive

02 HOMY WPC

Read All Section Before You Install

To get latest information,
please visit our website: www.homywpc.com

Profiles




Indoor WPC Wall Panel
Code: No-65
Size: 400(W)*71(T), 400(W)*8(T), 400(W)*9(T), 600(W)*8(T)

Indoor SPC Wall Panel
Code: RFD3 Engineer Wood 1
Size: 400(W)*8(T), 400(W)*11(T), 400(W)*8(T), 600(W)*8(T)

Accessories


Note: You can determine your own accessories according to the installation area.



03 HOMY WPC

Installation Process

1. High Gloss UV Board Installation Process




- 1.Put the double-sided tapes at the edges of the board and put adhesives in the middle of the boards as shown in the picture.
- 2.Put UV boards on wall and please make sure that seams between 2 boards are tight enough and then install aluminum accessories on the seams.
- 3.Finished UV boards effect.

04 HOMY WPC

2. Indoor WPC Wall Sheet Installation Process



1. Make the wall base in same level



2. Put adhesives on the back of WPC wall sheet and then install WPC wall sheet on the wall.



3. Install the aluminum accessories on the seams.



4.Finished WPC wall sheet effect.

05 HOMY WPC

Final Installation Effect



06 HOMY WPC

07 HOMY WPC